

THE VINTAGE SHOP
SPIGOT WRENCH



Items Needed:

- PET Carboy with a 1" hole.
- The Vintage Shop Spigot or Easy On/Off Spigot.
- The Vintage Shop Spigot Wrench

Installing Spigot:



- Place PET carboy with hole side facing up.
- Place nut into the Spigot Wrench.
- Place spigot body into the hole of the carboy, making sure that the o-ring is on the outside of the Carboy.
- Insert Spigot Wrench with the nut into the neck of the carboy, and reach to the threads on the Spigot.

-Start turning the spigot body clockwise to screw the nut on. You do not need to turn the nut at all.

-Once the nut is snug tight, check if the spout is in the desired position. If yes remove the tool from the carboy and test with water for leaks.

If the spout of the spigot is not in the desired position:



- Turn spigot counter clockwise to loosen the nut a little bit but still keeping it attached.
- Remove the tool from the nut.

- Rotate Spigot and nut counter clockwise at approximately the same angle that the spout was off from the vertical position.

- Once you turn the spigot to the right position, attach the Spigot Wrench to the nut and re-tighten. (*If still out of line repeat steps 1 -4*).

- Tighten the spigot by hand and Spigot Wrench only.

Fill up Carboy with water and test for leaks.

